

2015 Trophy Cam Aggressor Firmware Update Instructions

1. Acquire the correct firmware for your Trophy Cam HD Aggressor from <http://bushnell.com/global/customer-service/trophycam-software>
2. Click on the appropriate firmware version to begin downloading the .zip file.
3. Open the .zip file.
4. Drag both files (.elf and spec.bin) to your desktop. Or you can right click the downloaded .zip file and select "extract all"
5. Insert SD card into computer / SD card reader and open, you should either see a blank screen, or one folder labeled "DCIM."
 - a. If any file exist on the SD Card it is best to format the card.
6. Copy .elf and spec.bin files onto SD card. (DO NOT place into DCIM folder)
7. Remove SD card from computer once the files have been copied.
8. Insert SD card into your Trophy Cam, along with a new set of 8 – AA Batteries.
9. Press and hold the Up Arrow button. (Far left button)
10. While holding the Up Arrow, slide the power switch to "setup."
11. A Green LED (on the front of the camera) will begin flashing and you can release the Up Arrow. (The Green LED is located in the same location as the RED PIR indicating LED, which will flash as well when motion is detected.)
12. When Green LED stops flashing, the update is complete.
13. Power OFF your Trophy Cam when the update is complete.
14. To double check Firmware version, slide the power switch to "SETUP." Press the "MENU" button and then press the "LEFT" arrow key. Firmware version will be displayed.